

AIRWAVES



SC72-105 - SC48-040 - SC3202

Remove Before Flight Flags

1. Cut flags out with sharp knife.
2. Add thin wire for location pin in the middle of the reverse side of the RBF flag.
3. Lightly moisten one side of the self adhesive on the reverse RBF flag.
4. Fold over and apply light pressure.
5. Attach to model.
6. Some RBF'S have a gloss finish.

If this is requires, apply gloss paint.

